Note: A dot inside a square indicates there is sufficient oil in the pump to operate the cylinder to maximum extension. Although some pumps and cylinders are compatible, the useable oil capacity in both are so close that longer hoses (requiring more oil) that connect both components may prevent the pump from operating the cylinder to maximum extension.

PUMPS (Pages 38-39)	970070	9700264	9700274	9700284	9700294	970030	91004S	97004>	915006	25023	25024	250254	9505g	250274	33003	33008	350005	3550194	355065	35070	355106	39900	399706
910017B		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•			
910018B		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•		•	
910019B		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•		•	
910020		•	•	•	•	•	•	•	•	•		•	•		•		•		•	•			
910052A		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•			
910130A		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•		•	
910140		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•		•	
910165		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•		•	
925009A		•	•	•									•		•								
925010B		•	•	•	•	•	•	•	•	•		•	•		•		•		•	•			
925011		•	•	•	•	•	•	•	•	•		•	•		•		•		•	•			
925012A		•	•	•	•	•	•	•	•	•		•	•		•		•		•	•			
925013B		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•			
925014	•															•					•		