

## **11060** DUAL AGRICULTURAL BEAD BREAKER

## **Dual Agricultural Tire Bead Breaker**

- Guaranteed to break any dual ag tire beads regardless of vehicle
- Unique compact design allows the tool to fit in the tightest spaces only 3" (7.6 cm) wide at narrowest point
- Spreads to 26" (66 cm) in width enough to break any bead
- Used to break the inside bead of the outside tire on a dual assembly
- Can also be used to break inside bead of inside tire, when tool is placed against the frame of vehicle
- 10 Ton cylinder has enough force to break all tractor beads
- Used with 10,000 PSI (700 bar) air/hydraulic pump
- Weight 39 lbs (17.6 kg)




2347 Circuit Way Brooksville, FL 34604 352.799.1111 - sales@ameintl.net







**Dual Agricultural Tire Bead Breaker** 



2347 Circuit Way Brooksville, FL 34604 352.799.1111 - sales@ameintl.net



www.ameintl.net