




# 11040

## OTR TIRE BEAD BREAKER

### OTR Tire Bead Breaker

- Original Earth Mover tire bead breaker, originally marketed as Goodyear TO-100-HA
- Tool clamps to wheel mechanically and then the hydraulic ram assembly is used to break the bead
- Designed for use on 5 piece wheels which do not have bead loosening pockets
- Tool offers 10" (25.4 cm) of stroke to break the bead
- Includes 6 curved wedges which are used to prevent tire from 're-seating' when the tool is moved around the wheel for additional bead breaking
- Used with 10,000 PSI (700 bar air/hydraulic pump or hand operated hydraulic pump)
- Model 12150 – Frame Assembly only (TO-100-FA)
- Model 12160 – Ram Assembly only (TO-100-RA)
- Weight: 52 lbs (23.5 kg)



2347 Circuit Way  
Brooksville, FL 34604  
352.799.1111 - sales@ameintl.net





# 11040

## OTR TIRE BEAD BREAKER

OTR Tire Bead Breaker



Scan this QR code for a  
video demonstration!



Frame Assembly available.  
For complete parts breakdown,  
visit [www.beadbreakers.com](http://www.beadbreakers.com)

2347 Circuit Way  
Brooksville, FL 34604  
352.799.1111 - [sales@ameintl.net](mailto:sales@ameintl.net)

[www.ameintl.net](http://www.ameintl.net)

