




PARTS BREAKDOWN

Parts List For

Air Hydraulic Pump

15000



DETAIL A



PARTS BREAKDOWN

Parts List For Air Hydraulic Pump

15000

Item	Part No.	Qty	Description	Item	Part No.	Qty.	Description
1	15000-201	1	Hydraulic Cylinder	23	15000-223	1	Plunger
2	15000-202	1	Washer	24	15000-224	1	Poppet
3	15000-203	2	O-Ring	30	15000-180	1	Screw- .250-20 Special
4	15000-204	1	Mtg. Bracket	31	15000-181	1	B/U Washer
5	15000-205	1	Bowed Ret. Ring	32	15000-182	1	Piston
6	15000-206	1	Relief Valve Assy	33	15000-183	1	O-Ring
7	15000-207	2	Copper Gasket	34	15000-137	1	O-Ring
8	15000-208	2	Seat	35	15000-185	1	Air Motor, Complete
9	15000-209	2	1/4" Dia. Ball	36	15000-186	1	O-Ring
10	15000-210	1	Conical Spring	37	15000-187	1	O-Ring Ref M760041
11	15000-211	2	Ball Guide	38	15000-188	4	O-Ring Ref K1041
12	15000-212	1	Copper Gasket	39	15000-189	1	1/16 Flush Plug
13	15000-213	1	Pressure Tube	41	15000-190	4	Screw, Torx
14	15000-214	2	Backup Ring	42	15000-191	1	Extension Fitting, Air Motor
15	15000-215	2	O-Ring	43	15000-174	1	Retaining Pin
16	15000-216	1	U-Cup	44	15000-193	1	Air Motor Piston
17	15000-217	1	Bearing	47	15000-194	1	O-Ring
18	15000-218	1	Bearing Retainer	48	15000-195	2	Clamp Brk.
19	15000-219	1	Conical Spring	49	15000-196	1	Hose Clamp
20	15000-220	1	Spring	50	15000-198	1	Glyde Ring
				51	15000-197	1	O-Ring
21	15000-221	1	Rubber Washer	52	15000-252	1	Intake Tube Assy
22	15000-222	1	Spring Washer	53	15000-253	1	O-Ring Ref. C403503


2347 Circuit Way, Brooksville, Florida, USA 34604
Phone: (+1) 352-799-1111 Toll Phone: (+1) 877-775-4AME (4263)
Fax: (+1) 352-799-1112 E-mail: sales@ameintl.net www.ameintl.net



PARTS BREAKDOWN

Parts List For Air Hydraulic Pump

15000





PARTS BREAKDOWN

Parts List For Air Hydraulic Pump


15000

Item	Part No.	Qty	Description	Item	Part No.	Qty.	Description
1	15000-125	1	Ret. Ring	63	15000-153	1	Stamped Bracket
2	15000-126	1	Spring Washer	64	15000-154	1	Ret. Ring
3	15000-127	1	Cap	65	15000-155	1	O Ring Ref
4	15000-128	1	Release Plunger	66	15000-054	6	Hi Lo Screw
5	15000-129	1	Spring	67	15000-157	1	Air Tool Oil Decal
6	15000-130	1	Ball Seat	68	15000-158	1	Caution Decal
7	15000-131	1	Gasket	69	15000-159	1	Gasket Set
8	15000-132	1	Gasket	70	15000-160	1	Filter
9	15000-133	1	7/32" Dia. Ball	71	15000-161	1	O-Ring
10	15000-134	1	Manifold	72	15000-162	1	1/4 x 3/8 Hi Lo Screw
11	15000-135	4	Thd. Form Screw	73	15000-163	1	Air Button
12	15000-136	1	B/U Washer	77	15000-164	1	Breather
13	15000-137	1	O-Ring	78	15000-165	1	3/8 Flush Plug W/Sealant
14	15000-138	1	O-Ring	79	15000-166	1	O-Ring (Wear Coated)
15	15000-139	1	Back-up Washer	80	15000-167	1	O-Ring
16	15000-140	1	O-Ring	81	15000-168	1	Poppet
17	15000-141	1	Plug	82	15000-169	1	Breather Vent Decal
18	15000-142	1	Spring	83	15000-170	1	O-Ring Ref
19	15000-143	1	Release Guide	84	15000-171	1	Compression Spring
20	15000-144	1	Ball Guide	85	15000-172	1	3/16" Retainer
60	15000-150	1	Blk Cover Assy.	86	15000-173	1	Gasket
61	15000-151	1	Swivel Coupler	88	15000-174	1	Retaining Pin
62	15000-152	1	Filter	89	15000-175	1	Retaining Ring



PARTS BREAKDOWN

Parts List For Air Hydraulic Pump 15000





PARTS BREAKDOWN

Parts List For

Air Hydraulic Pump

15000

Item	Part No.	Qty	Description
1	15000-001	1	2 Gallon Reservoir
2	15000-002	1	Reservoir Gasket Top Plate
3	15000-003	1	Plate
4	15000-004	10	BHC Screw
5	15000-005	14	Lock Washer
6	15000-006	14	Hex Nut
51	15000-051	1	Gasket
52	15000-052	1	Intake Tube
53	15000-253	1	O-Ring
54	15000-054	8	BHC Screw
55	15000-055	4	Capscrew
56	15000-056	12	Sealing Washer
57	15000-005	4	Lock Washer .25
58	15000-006	4	Hex Nut .25
90	15000-090	1	Muffler
91	15000-091	1	Muffler Cover
92	15000-092	2	Hi Lo Screw
94	15000-094	1	Treadle
95	15000-095	2	Shoulder Screw
110	15000-110	4	Screw