




PARTS AND ELECTRICAL MANUAL



JOINTER / PLANER MODEL: JP-1898-NC

Baileigh Industrial, Inc.
P.O. Box 531
Manitowoc, WI 54221-0531
Phone: 920.684.4990
Fax: 920.684.3944
sales@baileighindustrial.com


REPRODUCTION OF THIS MANUAL IN ANY FORM WITHOUT WRITTEN APPROVAL OF BAILEIGH INDUSTRIAL, INC. IS PROHIBITED. Baileigh Industrial, Inc. does not assume and hereby disclaims any liability for any damage or loss caused by an omission or error in this Operator's Manual, resulting from accident, negligence, or other occurrence.

Table of Contents

COMPLETE ASSEMBLY	1
Cutter Block A.....	6
Cutter Block B.....	7
Thicknessing Table A	11
Thicknessing Table B	12
Infeed Table A	15
Infeed Table B	16
Outfeed Table A	19
Outfeed Table B	20
Angle Fence A	23
Angle Fence B	24
Deceleration	27
Electrical Control Assembly A.....	30
Electrical Control Assembly B.....	31
Safety Guard A.....	34
Safety Guard B	35
Safety Guard II A (optional)	38
Safety Guard II B (optional)	39
Electrical Diagram A	42
Electrical Diagram	43
Electrical Diagram C.....	44
Electrical Diagram D.....	45
Electrical Diagram E	46



COMPLETE ASSEMBLY





Item	Descriptions	Specifications	Qty.
1	Motor,	2hp-6p	1
2	Washer		1
3	Motor	7.5hp-4p	1
4	Angle Fence	46a	1
5	Operation Instructions	Ch525	1
6	Cutterblock	46a	1
7	Handwheels	Da7307-125	1
8	Deceleration	46a	1
9	Aluminum Hinges	CI-208-3	2
10	Electrical Box Layout	53a	1
11	Emergency Stop Button		2
12	Hole Plugs	Hp-13	13
13	Hole Plugs	16	2
14	Hole Plugs	19	1
15	In-Feed Table	46b	1
16	Counter Sunk Head Cap Screw	M4-8	2
17	Counter Sunk Head Cap Screw	M5-8	16
18	Counter Sunk Head Cap Screw	M8-16	2
19	Counter Sunk Head Cap Screw	M8-20	4
20	Phillips Head Screw	M5-30	4
21	Button Head Screw	M5-12	10
22	Button Head Screw	M6-12	28
23	Button Head Screw	M6-20	4
24	Cap Screw	M10-20	6
25	Cap Screw	M10-40	8
26	Cap Screw	M10-45	4
27	Cap Screw	M5-12	8
28	Cap Screw	M5-16	3
29	Cap Screw	M6-16	16
30	Cap Screw	M6-20	3
31	Cap Screw	M6-25	18
32	Cap Screw	M8-20	2
33	Cap Screw	M8-25	15
34	Set Screw	M10-100	1



Item	Descriptions	Specifications	Qty.
35	Set Screw	M10-16	2
36	Set Screw	M10-80	1
37	Set Screw	M6-10	2
38	Set Screw	M6-16	22
39	Set Screw	M8-10	7
40	Set Screw	M8-16	12
41	Hex Head Bolt	M10-30	4
42	Hex Head Bolt	M10-35	18
43	Hex Head Bolt	M8-20	4
44	Hex Nut	M10	7
45	Hex Nut	M12	2
46	Hex Nut	M5	8
47	Hex Nut	M6	8
48	Lock Washer	10mm	34
49	Lock Washer	6mm	8
50	Lock Washer	8mm	8
51	Washer	10x21	8
52	Washer	6x12.5	4
53	Washer,	8x17	4
54	Parallel Key	10-8-56	1
55	Parallel Key	5-5-14	1
56	Parallel Key	6-6-45	1
57	Parallel Key	8-7-40	1
58	Ball Bearing	6004-2nsI	2
59	Ball Bearing,	601-2nsI	1
60	Ball Thrust Bearing	51102	2
61	Retaining Rings For Hole	R28	1
62	Limit Switch	Tz7311	2
63	Cable Gland	Mgb25-18	1
64	Waterproof Latches	Ms705-3a	2
65	Disconnection Switch	OHG65J5	1
66	Out-Feed Table	46a	1
67	Power Resistor	Rv24yn20s	1
68	3-Notch Key Spring Return		1
69	Stand		1




Item	Descriptions	Specifications	Qty.
70	Cover		1
71	Cover		1
72	Control Panel		1
73	Control Panel		1
74	Paper		1
75	Adhesive Paper		1
76	Adhesive Paper		1
77	Stickers		1
78	Cover		1
79	Cover		1
80	Cover		1
81	Motor Base		1
82	Motor Base		1
83	Shaft		2
84	Cover		4
85	Cover		1
86	Electrical Control Cover		1
87	Adjustment Bracket		1
88	Cover		1
89	Adjustment Shaft		1
90	Indicator Board For IN-FEED TABLE		1
91	Tension Springs		1
92	Set Collars		1
93	Rotate Collars		1
94	Shaft		2
95	Screw		1
96	Nut		1
97	Guide Rails		2
98	Protecting Cover		1
99	Protecting Cover		1
100	Cover		1
101	Cover		1
102	Bearing with Holder		1
103	Bearing Caps		1
104	Washer		4



Item	Descriptions	Specifications	Qty
105	Shaft		1
106	Rings		1
107	Feeding Pulley	B	1
108	Feeding Pulley	A	1
109	Spindle Pulley	B	1
110	Sprockets	RS40-10T	1
111	Sprockets	RS40-13T	1
112	Adjustment Bracket		1
113	Adjustment Bolt		1
114	Belt	SPZ1837LW	3
115	Belt	SPZ1237LW	1
116	Rs40-114		1
117	Adjustment Bracket		1
118	Bushings		1
119	Scale Plate		1
120	Scale Plate		1
121	Safety Guard	46a	1
122	Start White, On		3
123	Stop Black, Off		2
124	Thicknessing Table	46b	1




Cutter Block A





Cutter Block B



⬡ : Option



Item	Descriptions	Specifications	Qty.
1	Counter Sunk Head Screw	M12-30	2
2	Counter Sunk Head Screw	M5-10	30
3	Counter Sunk Head Screw	M6-16	4
4	Phillips Head Screw	M3-20	2
5	Phillips Head Screw	M3-5	2
6	Button Head Screw	M5-10	4
7	Cap Screw	M10-25	2
8	Cap Screw	M10-35	4
9	Cap Screw	M6-16	6
10	Cap Screw	M6-20	6
11	Cap Screw	M6-20	4
12	Cap Screw	M8-12	11
13	Set Screw	M12-20	32
14	Set Screw	M10-100	4
15	Set Screw	M4-6	2
16	Set Screw	M5-6	4
17	Set Screw	M6-16	2
18	Set Screw	M8-10	2
19	Set Screw	M8-16	8
20	Set Screw	M8-25	11
21	Set Screw	M8-35	11
22	Set Screw	M8-8	8
23	Hex Head Screw	M6-16	6
24	Hex Head Screw	M8-30	2
25	Hex Nut	M10	8
26	Hex Nut	M6	2
27	Hex Nut	M8	22
28	Hex Nut	M8	2
29	Washer	10x21	4
30	Parallel Key	10-8-32	2
31	Parallel Key	12-8-40	1
32	Ball Bearing	6006-2nsI	4
33	Ball Bearings	6208-C3 & 6208-Cm	2
34	Spanner Lock Nut	An06	2
35	Spanner Lock Nut	An08	2




Item	Descriptions	Specifications	Qty.
36	Ext Tooth Washer	AW06	2
37	Ext Tooth Washer	Aw08	2
38	Retaining Rings For Hole	R55	4
39	Oil Free Bushings	Lfzb25-10	2
40	Cutterhead		1
41	Roller Shaft		1
42	Shaft		2
43	Back Lock Bar		1
44	Set Collars		1
45	Spring Seat		1
46	Pressure Bar		1
47	Safe Cover		1
48	Rubber Roller		1
49	Set Collars		1
50	Flat Knife	465mm	4
51	Lock Bar For Knife		4
52	Cover		1
53	Lock Bar		1
54	Rubber For Dust Keeper		1
55	Bearings With Holder		4
56	Cutterhead Bearings With Holder		1
57	Cutterhead Bearings With Holder		1
58	Bearing Cover		2
59	Ring		1
60	Front Lock Bar		11
61	Nut		4
62	Wire Spring,	20-2.5-57.5I	4
63	Arm, R		1
64	Arm, L		1
65	Slide Guides		1
66	Slide Guides		1
67	Lock Bar		3
68	Cover		1
69	Roller Shaft		1
70	Roller Shaft		1



Item	Descriptions	Specifications	Qty.
71	Rings		2
72	Locating Pins		4
73	Rings		2
74	Rollers, L		11
75	Rubbers		44
76	Wire Spring	20-2.2-35l	11
77	Wire Spring	36-2.5-37.5l	2
78	Tension Springs	8x1x76l	2
79	Bracket		1
80	Dogs		1
81	Lock Bar		1
82	Washer		2
83	Set Collar		4
84	Spindle Pulley, A		1
85	Sprockets	RS40-34T	2
86	Proximity Switch,	TI_Q5mc1	1
87	Spring Seat For Cutterhead		8




Thickening Table A





Thickening Table B






Item.	Description	Specification	Qty
1	Control Knobs	7041-50-B8	1
2	Cap Screw	M10-25	2
3	Cap Screw	M10-30	8
4	Cap Screw	M5-12	28
5	Cap Screw	M6-16	7
6	Cap Screw	M8-25	2
7	Cap Screw	M8-30	8
8	Cap Screw	M8-35	4
9	Set Screw	M5-8	1
10	Set Screw	M6-16	2
11	Set Screw	M6-25	1
12	Set Screw	M6-6	8
13	Set Screw	M8-10	10
14	Set Screw	M8-30	4
15	Hex Head Bolt	M10-30	4
16	Hex Nut	M10	2
17	Hex Nut	M10	2
18	Hex Nut	M8	8
19	Lock Washer	10mm	8
20	Lock Washer	6mm	7
21	Lock Washer	8mm	4
22	Washer	10X21	8
23	Washer	6X12.5	7
24	Ball Bearing	6005-2NSL	4
25	Retaining Rings For Shaft	S25	4
26	Retaining Rings For Shaft	S47	4
27	Oil Free Bushings	LFZB25-15	4
28	Oil Free Bushings	LFZB25-35	4
29	Rollers		2
30	Shaft		2



Item	Description	Specification	Qty
31	Thicknessing Table		1
32	Bracket		2
33	Shaft		2
34	Stretch Table		1
35	Dogs		1
36	Set Collars		4
37	Bracket		2
38	Shaft		4
39	Plates		2
40	Bracket		2
41	Adjustment Plate		1
42	Rough Guides	A	4
43	Rough Guides	B	4
44	Adjustment Bolt		1
45	Set Collars		1
46	Adjustment Bolt		4
47	Rough Guides	C	4
48	Slide Guides		2
49	Guide Ralls		2
50	Bushings		1
51	Indicator Board		1
52	Stickers		1
53	Grease Nipples	M6X45	4



Infeed Table A








Item	Description	Specification	Qty.
1	Gear Lever Handles	1162-M10-160	2
2	Counter Sunk Head Cap Screw	M12-35	8
3	Counter Sunk Head Cap Screw	M8-20	2
4	Button Head Screw	M5-10	2
5	Button Head Screw	M5-12	8
6	Cap Screw	M12-50	4
7	Cap Screw	M5-12	8
8	Cap Screw	M5-16	2
9	Cap Screw	M6-20	5
10	Cap Screw	M8-30	4
11	Cap Screw	M8-40	4
12	Set Screw	M12-12	8
13	Set Screw	M6-10	1
14	Set Screw	M8-10	23
15	Hex Nut	M10	2
16	Hex Nut	M8	2
17	Hex Nut	M2	2
18	Lock Washer	12mm	4
19	Lock Washer	5mm	10
20	Lock Washer	6mm	5
21	Lock Washer	8mm	2
22	Washer	5X12	10
23	Retaining Rings	E Type, E19	1
24	Oil Free Bushings	LFZB15-15	1
25	Oil Free Bushings	LFZB20-15	1
26	Position Transducers	LS1510	1
27	Thrust Bearing	NTB25424	16
28	In-Feed Table		1
29	Table Lips		1
30	Dust Keeper		1
31	Arm		4
32	Washer		8
33	Links	A	1
34	Links	B	1
35	Links	C	1



Item	Description	Specification	Qty.
36	Posts For Tension Springs		2
37	Holders For Tension Springs		2
38	Bushings		2
39	Bushings		2
40	Washer	30x10x4t	2
41	Links		2
42	Washer	20x12x5t	4
43	Links Shaft		8
44	Tension Springs		2
45	Bushings		8
46	Pulls Keepers	R	1
47	Set Collars		1
48	Pulls Keepers	L	1
49	Washer		2
50	Set Collars		1
51	Shaft		1
52	Shaft		1
53	Shaft		1
54	Bushings		2
55	Links		1
56	Links		1
57	Guides		1
58	Bracket For Position Transducers		1
59	Links	G	1
60	Guard	5"	1
61	Washer		2




Outfeed Table A





Outfeed Table B






Item	Description	Specification	Qty
1	Gear Lever Handles	1162-M10-160	2
2	Hand Knobs	6020-63-M12	1
3	Counter Sunk Head Cap Screw	M12-35	8
4	Cap Screw	M12-50	4
5	Cap Screw	M5-16	2
6	Cap Screw	M6-20	5
7	Cap Screw	M8-25	8
8	Cap Screw	M8-30	6
9	Cap Screw	M8-40	4
10	Set Screw	M12-12	8
11	Set Screw	M6-10	6
12	Set Screw	M8-10	24
13	Hex Nut	M10	2
14	Hex Nut	M8	2
15	Lock Washer	12mm	4
16	Lock Washer	6mm	5
17	Lock Washer	8mm	6
18	Thrust Bearing	NTB25424	16
19	OUT-FEED TABLE		1
20	Table Lips		1
21	Depth Cut Limiter		1
22	Shaft		1
23	Shaft		1
24	Arm		4
25	Washer		8
26	Links	D	1
27	Link	E	1
28	Link	F	1
29	Anti-kickback Fingers		45
30	Block		2



Item	Description	Specification	Qty
31	Rings		46
32	Holders		1
33	Holders		1
34	Posts For Tension Springs		2
35	Holders For Tension Springs		2
36	Bushings		2
37	Links		2
38	Bushings		2
39	Fixed Panel		1
40	Adjustable Panel		1
41	Adjustable Shaft		1
42	Washer	30x10x4t	2
43	Washer	20x12x5t	4
44	Links Shaft		8
45	Tension Springs		2
46	Bushings		8
47	Pulls Keeper	R	1
48	Set Collars		1
49	Pulls Keeper	L	1
50	Washer		2
51	Set Collars		1
52	Set Collars		1
53	Link	H	1



Angle Fence A







Item	Description	Specification	Qty
1	Gear Lever Handles	162-M10-160	2
2	Indexing Plungers	9010-6	2
3	Adjustable Hand Levers	M12-45	1
4	Counter Sunk Head Screw	M8-20	4
5	Button Head Screw	M5-12	2
6	Cap Screw	M10-35	4
7	Cap Screw	M10-40	2
8	Cap Screw	M12-60	1
9	Cap Screw	M5-12	14
10	Cap Screw	M8-12	1
11	Cap Screw	M8-20	2
12	Cap Screw	M8-25	6
13	Set Screw	M12-90	1
14	Set Screw	M6-6	4
15	Set Screw	M8-10	9
16	Set Screw	M8-40	1
17	Hex Head Bolt	M10-30	1
18	Hex Head Bolt	M10-35	1
19	Hex Head Bolt	M8-30	2
20	Hex Nut	M12	2
21	Hex Nut	M5	1
22	Hex Nut	M8	5
23	Lock Washer	10mm	2
24	Lock Washer	5mm	8
25	Lock Washer	8mm	6
26	Washer	10X21	1
27	Washer	5X10	8
28	Ball Bearing	6001-2NSE	2
29	Retaining Rings For Shaft	S12	2
30	Retaining Rings For Shaft	S16	1
31	Dust Keeper		1
32	Fence Shaft		1
33	Brush		2
34	Parallel Key		1
35	Angle Fence		1



Item	Description	Specification	Qty
36	Side Plate		1
37	Arm		2
38	Lock Seat		2
39	Links		2
40	Fence Seat		1
41	Links		1
42	Links		1
43	Links Shaft		1
44	Rollers		2
45	Links Shaft		1
46	Links Shaft		1
47	Lock Shaft		1
48	Eccentric Wheel		2
49	Turn Collars		1
50	Washer		1
51	Turn Collars		1
52	Turn Collars		2
53	Fixed Panel		1
54	Fixed Panel		1
55	Screw Seat		1
56	Pulls Seat		1
57	Torsion Springs		2
58	Bracket		1
59	Parallel Key		1
60	Lock Seat		1
61	Indicator Board		1
62	Adjustment Screw		4




Item	Description	Specification	Qty
1	Motor	0.5HP	1
2	Couplings	D20-20L	1
3	Encoder	200P	1
4	Hose Fittings	3"	4
5	Hose Fittings	3.5"	4
6	Phillips Head Screw	M3-10	4
7	Cap Screw	M10-25	4
8	Cap Screw	M4-10	16
9	Cap Screw	M6-16	8
10	Cap Screw	M6-20	8
11	Cap Screw	M6-25	12
12	Set Screw	M10-80	2
13	Set Screw	M4-6	4
14	Set Screw	M5-6	4
15	Set Screw	M6-6	8
16	Set Screw	M8-10	8
17	Set Screw	M8-10	2
18	Hex Head Bolt	M10-30	4
19	Hex Head Bolt	M8-25	4
20	Hex Nut	M10	4
21	Lock Washer	10mm	4
22	Lock Washer	4mm	4
23	Lock Washer	6mm	8
24	Lock Washer	8mm	4
25	Washer	10*21	2
26	Washer	6*12.5	5
27	Washer	8*17	4
28	Parallel Key	8-7-40	1
29	Ball Bearing	6001-2NL	1
30	Ball Thrust Bearing	51110	8



Item	Description	Specification	Qty
31	Spanner Lock Nut	AN10	4
32	Ext Tooth Washer	AW10	4
33	Retaining Rings For Hole	R28	1
34	Aluminum Alloy Worm Reducers	NEM-50	1
35	Flexible Bellow		4
36	Ball Screw Nut Holder		4
37	Screw Covers	A	4
38	Screw Covers	B	4
39	Sponges		4
40	Rolling Ball Screw		4
41	Rings		4
42	Sponges		4
43	Adjustment Collars		4
44	Washer		4
45	Bearings Holder		4
46	Sprockets	RS40-18T	4
47	Sprockets	RS40-27T	1
48	Cover Caps		4
49	Adjustment Ring		4
50	Cover		1
51	Sprockets Bracket		1
52	Washer		4
53	Sprockets	RS40-13T	1
54	Grease Nipples	M6	4



Electrical Control Assembly A








Item	Description	Specification	Qty
1	Cabinet "U" Handles		1
2	Adjustable Hand Levers	4020-80-M10-40	1
3	Operation Instructions	M10e	1
4	Digital Panel Meter	CMHPP1A	1
5	Caps	100X50X3T	2
6	Emergency Button		1
7	Phillips Head Screw	M5-8	4
8	Button Head Screw	M5-10	6
9	Cap Screw	M6-12	5
10	Cap Screw	M6-16	3
11	Cap Screw	M6-20	2
12	Cap Screw	M6-30	3
13	Cap Screw	M8-16	3
14	Cap Screw	M8-25	2
15	Hex Nut	M-8	2
16	Lock Washer	6mm	7
17	Washer	6X12.5	7
18	R9C01VN		2
19	R9C10VN		5
20	R9PDNVO		2
21	RV24YN20S	5K	1
22	3-Notch Key Spring Return		1
23	Control Panel Arm		1
24	Control Panel		1



Item	Description	Specification	Qty
25	Ring		1
26	Panel		1
27	Ring		1
28	Cover		1
29	Arm		1
30	Turn Collar		1
31	Turn Collar		1
32	Set Collar		1
33	Links		1
34	Cover		1
35	Adhesive Paper		1
36	Button, On		2
37	Button, Off		1




Safety Guard A





Safety Guard B






NO.	Description	Specification	Qty
1	Ball Bearing	6000-2NSE	1
2	Gas Cylinders	16-1-186-60	1
3	Hand Knobs	6020-50-M10	1
4	Hand Knobs	6050-40-M8-30	1
5	Counter Sunk Head Cap Screw	M5-20	1
6	Counter Sunk Head Cap Screw	M8-20	2
7	Counter Sunk Phillips Head Screw	M5-10	8
8	Button Head Screw	M5-10	6
9	Cap Screw	M6-12	4
10	Cap Screw	M8-12	1
11	Cap Screw	M8-20	5
12	Set Screw	M5-10	2
13	Set Screw	M8-16	6
14	Hex Nut	M10	2
15	Hex Nut	M8	1
16	Lock Washer	10mm	2
17	Lock Washer	6mm	4
18	Lock Washer	8mm	2
19	Washer	6X2.5	4
20	Washer	8X17	2
21	Retaining Rings For Shaft	S12	2
22	Retaining Rings	For E Type, E7	1
23	Spring Pins	4-10	2
24	Oil Free Bushings	LFZB12-8	1
25	Oil Free Bushings	LFZF12-10	8
26	Safety Guard	A1	1
27	Safety Guard	A2	1
28	Tension Springs	8X1X76L	2
29	Links		1
30	Panel		1



Item	Description	Specification	Qty
31	Caps		2
32	Adjustment Shaft		1
33	Aluminum Bracket		1
34	Shaft For Ball Bearing		1
35	Seat		1
36	Shaft		2
37	Shaft		1
38	Links		1
39	Links		1
40	Shaft		1
41	Shaft		1
42	Seat		1
43	Bracket		1
44	Cover		1
45	Shaft		2
46	Shaft		2
47	Shaft		2
48	Lock Bar		1
49	Shaft		1
50	Washer		1
51	Shaft		2
52	Bracket		1
53	Wire Springs	14-9-0.9	1




Safety Guard II A (optional)





Safety Guard II B (optional)






Item	Description	Specification	Qty.
1	Gas Cylinders	30-1-57-20-70N	1
2	Counter Sunk Head Cap Screw	M4-12	1
3	Counter Sunk Head Cap Screw	M5-12	8
4	Counter Sunk Head Cap Screw	M6-10	1
5	Linear Bushings	JB-16A	4
6	Bushings For Locating Pin	JBH10-8	1
7	Counter Sunk Phillips Head Screw	M3-6	8
8	Phillips Head Screw	M3-6	5
9	Phillips Head Screw	M5-10	4
10	Phillips Head Screw	M6-10	7
11	Cap Screw	M5-12	2
12	Cap Screw	M5-20	2
13	Cap Screw	M6-35	2
14	Cap Screw	M6-55	2
15	Cap Screw	M8-20	2
16	Cap Screw	M8-30	1
17	Set Screw	M6-10	1
18	Set Screw	M8-25	1
19	Hex Nut	M8	2
20	Lock Washer	6mm	4
21	Lock Washer	8mm	2
22	Washer	6X12.5	1
23	Ball Bearing	629-ZZ	8
24	Ball Bearing	696-ZZ	1
25	Retaining Rings For Shaft	S10	1
26	Retaining Rings	For E Type, E5	1
27	Spring Pins	3-25	1
28	Spring Pins	4-10	2
29	Spring Pins	8-20	1
32	Tension Springs	8X1X76L	2
33	Caps		1
30	Safety Guard	A1	1
31	Safety Guard	A2	1
34	Shaft		2
35	Shaft		2



Item	Description	Specification	Qty.
36	Shaft		2
37	Rollers		4
38	Shaft		2
39	Shaft		2
40	Washer		4
41	T-Plate		1
42	Shaft		1
43	Seat		1
44	Levers		1
45	Locating Pins		1
46	Shaft		1
47	Collars		1
48	Spring Seat		1
49	Seat		1
50	Links		1
51	Plate		1
52	Shaft		2
53	Caps		1
54	Shaft		1
55	Levers		1
56	Wire Spring,	1.2-12.5	2
57	Adjustable Shaft		1
58	Washer		1
59	Cover		1
60	Cover		1
61	Cover		1
62	Stainless Wires	1-1400mm	1
63	Stainless Wires	1-1600mm	1
64	Power Spring	45N	1
65	Power Spring	15N	1
68	Adjustable Head Levers	M6-20	1
66	Shaft		1
67	Collars		1




Electrical Diagram A






Electrical Diagram







Electrical Diagram C






Electrical Diagram D





Electrical Diagram E





Item	Description	Type / Model	Technical Data
901	Start Button	R9C10VN + R9PDNVO	AC15-DC13 600V-10A + 2W 250V
902	Stop Button	R9C01VN	AC15-DC13 600V-10A
903	Key Button (Option)	R9C10VN + R9C10VN	AC15-DC13 600V-10A
904	Emergency Stop	R9C01VN	AC15-DC13 600V-10A
905	Start Button	R9C10VN + R9PDNVO	AC15-DC13 600V-10A + 2W 250V
906	Stop Button	R9C01VN	AC15-DC13 600V-10A
907	Start Button	R9C10VN + R9PDNVO	AC15-DC13 600V-10A + 2W 250V
908	Emergency Stop	R9C01VN	AC15-DC13 600V-10A
909	Power Resistor	RV24YN20S	5K Ω
910	Operation Instructions	M10-e	0V-110V-220V / 250V-1A
911	Relay	MY2NJ 220V	220/240VAC 250V-5A
912	Timer	SRD-30S-220V	220VAC 5A
913	Fuse	440002gG	10-38-4A-2P
914	Fuse	440002aM	10-38-4A-3P
915	Fuse	420002gG	10-38-6A-3P
916	Fuse	420004aM	10-38-20A-3P
917	Transformer	105*50	420V/220V-120VA
918	Frequency Trans.	VFD015E + KPE-LE02	1.5kw/2HP/3.3KVA/4.2A
919	Power Terminal		3P-30A
920	Ground		5P
921	Terminal	TS-015	25P
922	Magnetic Contactors	CU-11 3a1b	220VAC
923	Magnetic Contactors	HUO-11K 3a1b (2.1K)	220VAC Set 1.8A
924	Magnetic Contactors	CU-11 3a1a	220VAC
925	Magnetic Contactors	CU-11 3a1b	220VAC
926	Magnetic Contactors	CU-11 3a1b	220VAC
927	Magnetic Contactors	HUO-11K 3a1a (10K)	220VAC Set 8.5A



NOTES



NOTES



BAILEIGH INDUSTRIAL, INC. 1625 DUFEK DRIVE MANITOWOC, WI 54220

PHONE: 920. 684. 4990 FAX: 920. 684. 3944

WWW.BAILEIGHINDUSTRIAL.COM

BAILEIGH INDUSTRIAL, INC. 1455 S. CAMPUS AVENUE ONTARIO, CA 91761

PHONE: 920. 684. 4990 FAX: 920. 684. 3944

BAILEIGH INDUSTRIAL LTD. UNIT 1 FULLWOOD CLOSE

ALDERMANS GREEN INDUSTRIAL ESTATE

COVENTRY, CV2 2SS UNITED KINGDOM

PHONE: +44 (0)24 7661 9267 FAX: +44 (0)24 7661 9276

WWW.BIFABUK.CO.UK

BAILEIGH INDUSTRIAL GMBH HOFENER STRAßE 64

70736 FELLBACH

DEUTCHSLAND

WWW.BAILEIGHINDUSTRIAL.DE