Installation / Maintenance



Battery Replacement and Disposal

Part# DF-EZAP


- When the battery no longer holds a charge it is time to replace it.
- Refer to Dent Fix's website, www.dentfix.com, to place your order for a new battery and obtain directions on how to return the old battery.

NOTE: The battery must be returned to Dent Fix Equipment for proper disposal, batteries cannot go in the garbage.

Battery Removal

Model 6500

Remove the battery as follows:



- 1. Turn off the compressed air.
- 2. **CAUTION:** To avoid electrical shock hazard insert the safety key into the battery jack and attach the trigger lockout clip behind the trigger.
- 3. Carefully squeeze tabs together and slide air nozzle off of the StaticZAP Anti-Static Device.
- 4. Using a pair of tweezers or pliers remove emitter pin from the pin holder, then through the outlet hole of the ionizer. Dispose of the emitter pin. **CAUTION:** do not bend the pin holder.



1611 W. 135th St / Gardena, CA 90249-2505 **PHONE** 310 349 1940 / **EMAIL** info@dentfix.com / **WEB** www.dentfix.com

Original Instructions INST6500BAT = 9/10


Installation / Maintenance




Battery RemovalPart # DF-EZAP

Remove the battery as follows: (cont'd)

5. Remove the four (4) phillips head screws.




6. Lift the housing top up off of the air gun.
Caution: do not over-stretch wires when opening the housing.



7. Squeeze latch on the wire connector and pull the connector apart to disconnect and remove the battery.

—Latch





1611 W. 135th St / Gardena, CA 90249-2505 **PHONE** 310 349 1940 / **EMAIL** info@dentfix.com / **WEB** www.dentfix.com

Original Instructions INST6500BAT – 9/10