


General Guidelines

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- The ramp must make FULL CONTACT with the ground. Do not use the ramp as a bridge under any circumstances.
- Rack Ramps are meant to only be used with vehicle tires.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measurements when using this product.
- Parts and/or instructions are subject to change without notice.



Safety

- Before using the ramps ensure other persons are clear of the vehicle and the ramps.
- Ensure that the ramps are free from damage before use.
- Do not exceed the rated weight capacity of 3,000 lbs. maximum axle capacity.
- Do not use with tires that exceed 12-inches in width.
- Only use on dry, level, hard surfaces. Do not use if tires are wet.
- Drive slowly and cautiously onto and off of the ramps. Never accelerate or brake suddenly.
- Another person, standing clear of the vehicle, should observe and guide the driver when using the ramps.



Operations

1. Inspect the ramps to make sure they are not damaged. Make sure your lift and vehicle are compatible with the ramps. NOTE: Your lift's resting height cannot exceed 5-inches.
2. With your lift in its resting height, be careful to properly position the Rack Ramp's "lip" onto the lift. Make sure that when positioned, the Rack Ramp is making full contact with the ground.
3. Check that the position of the Rack Ramps is in line with the vehicle wheels and that the steering wheel is pointed straight.
4. Carefully ascend the ramps in a slow and controlled manner until the vehicle is safely on the lift. Another person, standing clear and to the side of the vehicle, should guide the driver. Never accelerate or brake suddenly.

NOTE: Be careful to observe closely as the vehicle transitions from the Rack Ramp and onto the lift. Depending on your vehicle's wheelbase, it may be at risk of hi-centering or rubbing.

5. Once the vehicle is safely on the lift, the Rack Ramps may be removed.
6. When unloading the vehicle, place the Rack Ramp's "lip" onto the lift. Check that the position of the Rack Ramps is in line with the vehicle wheels and that the steering wheel is pointed straight. Carefully descend the ramps in a slow and controlled manner until the vehicle is safely on the ground.



Product Warranty and Liability

Race Ramps purchased from an authorized dealer or directly from Race Ramps LLC are backed by a one-year warranty. Our warranty is strictly limited to the repair or replacement of manufacturer defects and does not cover damage to a car, personal injury, labor, or any other damage or injury. Race Ramps LLC is not responsible for the damage caused by improper or unintended use. In no event shall Race Ramps LLC be responsible for consequential damage or costs. The warranty shall terminate one year from the date of purchase by the

original owner and is not transferable. Because we are continuously conducting research and development, specifications are subject to change without notice. Those items sold by Race Ramps LLC, but manufactured by other companies are subject to the manufacturer's warranty and policy.

Questions? Please contact Race Ramps at 800-213-5883 or email support@racerramps.com.